



# Trimming Your EZ ShowerBase

After you receive your EZ ShowerBase, insert the measuring tool into your existing set shower drain and take all 4 measurements.

Insert the measuring tool into your EZ ShowerBase and mark all 4 measurements.

In this example, you would need to make the following cuts to achieve your dimensions.

Left Side = 5", Right Side = 1", Bottom = 4".

These measurements are for the shower floor only and **DO NOT** include any 4" EZ Curb.

